



salton®

portable roaster oven



Instruction Booklet

Model RS1279

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. Place the roaster oven on a flat heat resistant surface and use in a well-ventilated area. Keep at least 4 - 6 " (10 - 15 cm) of space on all sides of the product to allow adequate air circulation.
3. **DO NOT** touch hot surfaces. Use pot holders or oven mitts when holding handles. **DO NOT** move the heated roaster oven.
4. When lifting or removing lid, avoid the vent holes on the lid and tilt the lid away to divert the escaping steam.
5. To protect against fire, electric shock and injury to persons, **DO NOT** immerse cord, plugs, or the appliance in water or other liquid.
6. Keep the product out of the reach of children. This product is not intended for use by children. Extra caution and close supervision are necessary when using any appliance near children.
7. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
8. **DO NOT** operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to Salton for examination, repair or adjustment. See "Warranty" section.
9. The use of accessories or attachments not recommended by Salton may cause hazards.
10. **DO NOT** use outdoors.
11. **DO NOT** let cord hang over edge of table or counter, or touch hot surfaces.
12. **DO NOT** place on or near a hot gas or electric burner, or in a heated oven.
13. Prior to connecting or disconnecting plug from wall outlet, turn any control to 'Off'.
14. This appliance is for Household Use Only. **DO NOT** use appliance for other than its intended use.
15. **DO NOT** leave unit unattended while in use.
16. Use extreme caution when moving an appliance containing hot oil or other hot liquids.
17. Use extreme caution when removing the Roasting Rack or the Removable Cooking Pan or when disposing of food, hot oils or other liquids.

18. Do not plug or unplug the product with wet hands.
19. Take proper precautions to prevent the risk of burns, fire or other personal or property damage as this appliance generates heat and escaping steam during use.
20. Do not store any materials not recommended by the manufacturer inside of the product when not in use.
21. Do not clean the product with metal scouring pads or harsh abrasive or chemicals cleaning pads.

SAVE THESE INSTRUCTIONS

HOUSEHOLD USE ONLY

POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.


INTRODUCTION

This versatile Roaster Oven can prepare anything that you would cook in a regular oven and more. The 'surround-heat' feature cooks food from all sides for moist, even results.

The Salton 'Roaster Oven' efficiently roasts ham, turkey and chicken to perfection; bakes pies, cakes and other delicious desserts; stews, steams and slow cooks. It is an ideal size for large family meals or entertaining.

DESCRIPTION OF PARTS

1. Cover
2. Cover Handle
3. Rack
4. Removable Cooking Pan
5. Base/Heating Well
6. Cover Rest Supports
7. Temperature Control Knob



BEFORE FIRST USE

Your Salton Roaster Oven should be conditioned before using for the first time. Follow the directions below:

1. Place the Roaster Oven on a flat, heat resistant surface in a well ventilated area or in a covered outside area.
2. Remove the Cover and lift out the Removable Cooking Pan.
3. Turn the Temperature Control Knob to the 'Off' position, then plug the unit into a 120 V outlet.
4. Set the Oven temperature to 425° – 450°F (218 – 230°C) and heat the empty Oven for 30 minutes until any odour/smoke disappears.
NOTE: This odour or smoke is normal when conditioning the Oven for the first time and will not reoccur once the Oven is properly conditioned.
5. After use, turn the Temperature Control Knob to 'Off', unplug unit from the outlet and allow the Roaster Oven to cool.
6. Wash the Cover, Rack and Removable Cooking Pan in warm soapy water.
DO NOT place in the dishwasher.
7. Wipe the interior and exterior of the Roaster Oven base with a damp cloth.
DO NOT IMMERSE THE ROASTER OVEN BASE IN WATER OR ANY OTHER LIQUID.

IMPORTANT: The Roaster Oven should be conditioned only before the first use. During normal use the Roaster Oven is preheated only until it reaches the preset temperature.

IMPORTANT NOTES:

- Do not use harsh or abrasive chemicals to clean the product.
- Never place anything except the Removable Cooking Pan into the Roaster Oven Base/Heating Well.
- Never place food or liquid(s) into the roaster Oven Base, always place food/liquid(s) into the Removable Cooking Pan.
- The Power Indicator Light will illuminate, indicating that the appliance is heating. The Light will shut off when the set temperature has been reached and will cycle on and off as the appliance maintains the set temperature.
- When removing the Cover, carefully remove it away from you as steam will be released when the Cover is opened.
- Check food for doneness but do not remove Cover continuously as this will result in heat loss and increased cooking time.

HOW TO USE

How To Use the Rack

The Folding Rack can be used when roasting meat or poultry or for steaming or baking. The small legs raise food so that there is air space underneath when roasting or baking and raise food above the water for steaming.

Unfold the side arms to the outside. Place food on the rack. Pick up the rack by the arms and place in the Cooking Pan. The arms of the rack will be held up by resting against the sides of the Cooking Pan. When food has finished cooking simply lift the rack by the arms to remove the food.

IMPORTANT: Always use oven mitts when removing the rack.

How to Use the Cover Rest

Place the edge of the Cover between the Handle and the Cover Rest Supports to keep the Cover and condensation inside the Cover off the counter or table.



How to Use The Roaster Oven

1. Place the Roaster Oven on a flat, heat resistant surface and use in a well ventilated area with 4 - 6" (10 - 15cm) of space on all sides of the product.
2. Turn the Temperature Control Knob to the 'Off' position. Plug into a 120V outlet.
3. Preheat the Roaster, with the Cover on, at the desired temperature until the Indicator Light goes out.
4. Follow the directions to either roast, stew, bake, steam or slow cook.
5. Use wood or plastic utensils to handle the food in the Cooking Pan.

How to Stew

1. Place the Removable Cooking Pan in the Base/Heating Well. Cover. Turn the Temperature Control Knob to the desired temperature and preheat the Roaster Oven until the indicator light goes out.
2. Cut food into uniform size pieces and place in the Removable Cooking Pan. Add liquids according to the recipe.
3. Cover.
4. Add liquids during cooking, if needed.

NOTE: If cooking frozen meat add 15 to 20 minutes to the recipe time. 5

How to Roast

1. Place the Removable Cooking Pan in the Base/Heating Well. Cover. Turn the Temperature Control Knob to the desired temperature and preheat the Roaster Oven until the indicator light goes out.
2. Place food on the Rack and lift into the Removable Cooking Pan.
3. Cover.
4. Turn the Temperature Control Knob to the desired temperature.
5. See the time chart below for the correct cooking time.

NOTE: To sear the meat before roasting, place the Removable Cooking Pan in the Base/Heating Well and preheat the Roaster Oven to 425°F (220°C). Add 1 tablespoon (15 ml) of cooking oil to the Removable Cooking Pan, add meat. Sear meat on all sides. Follow steps above to roast.

ROASTING TEMPERATURE AND TIME CHART

Times indicated in the chart are approximate and are for general guidelines only. Thicker cuts of meat may take longer to roast.

MEAT OR POULTRY	TEMPERATURE °F (°C)	INTERNAL TEMPERATURE °F (°C)	MINUTES PER LB. (PER KG)
Beef – Standing Rib (10 lbs./4.5 kgs.)	325° (160°)	140 (60) rare 160 (70) medium 170 (75) well done	18–20 (40–44) 22–25 (48–55) 27–30 (59–66)
Beef – Rolled Roast (10 lbs. /4.5 kgs.)	325° (160°)	140 (60) rare 160 (70) medium 170 (75) well done	30–32 (66–70) 35–38 (77–83) 40–45 (88–99)
Pork – fresh Boneless, rolled Bone-in (10 lbs./4.5 kgs)	350° (175°) 350° (175°)	185° (85°) well done 185° (85°) well done	35–40 (77–88) 30–35 (66–77)
Pork – smoked Ham, whole (12 lbs./5.5 kgs)	325° (160°)	170° (75°) well done	25–28 (55–61)
Lamb – leg (10 lbs. /4.5 kgs.)	325° (160°) 325° (160°)	150° (65°) medium 160° (70°) well done	26–28 (57–61) 29–31 (63–68)
Veal Boneless Bone-in (10 lbs./4.5 kgs.)	325° (160°) 325° (160°)	175° (80°) 175° (80°)	45–50 (99–110) 35–40 (77–88)
Turkey, stuffed (20 lbs./9 kgs.)	325° (160°)	195° (90°)	19–21 (41–46)

NOTE:

1. Large roasts require slightly less cooking time per pound than small roasts. Check internal temperature of roast during cooking for perfect results.
2. To cook an unstuffed turkey, reduce total cooking time by approximately 1 hour. Check internal temperature before serving.
3. Check internal temperature of poultry on the inside of the thigh.
4. When roasting, turn meat/poultry over halfway during the cooking process to avoid overcooking one side.
5. Defrost frozen foods before cooking them in the Roaster Oven.

How to Bake

1. Place the Removable Cooking Pan including the rack in the Base/Heating Well. Cover. Turn the Temperature Control Knob to the desired temperature and preheat the Roaster Oven until the indicator light goes out.
2. Place food in a pan, oven proof glass dish or foil and place on the Rack.
3. Cover.

NOTE:

1. To bake cobblers in casserole dishes, wrap foil around the edge of the crust for the first half of cooking time to prevent over-browning.
2. Follow package directions for cooking frozen foods such as entrees and pizza. For best heat circulation, place food on Rack.
3. Never place baking pans/dishes directions in the Roaster Oven Base, always use the Removable Cooking Pan.

How to Steam

1. Place the Removable Cooking Pan including the rack in the Base/Heating Well. Cover. Turn the Temperature Control Knob to the 400°F/200° C and preheat the Roaster Oven until the indicator light goes out.
2. Add 1/2" (12 mm) of liquid in the bottom of the Removable Cooking Pan.
3. Place food on the Rack or in a steaming basket.
4. Cover.

How to Slow Cook

1. Place the Removable Cooking Pan into the Base/Heating Well. Cover.
2. Turn the Temperature Control Knob to 250° – 275° (125°F – 135°C). and preheat until the indicator light goes out.
3. Add ingredients to the Removable Cooking Pan.
4. Stir and cover.
5. Follow recipe directions for cooking time.

NOTE:

1. During the slow cooking process, heat builds up very gradually producing a slow simmer. Stirring is not necessary during the slow cooking process. There is a minimum amount of escaping moisture so the amount of liquid in the recipe should be sufficient for the complete cooking time. However, if needed, replenish liquids sparingly.
2. To slow cook a standard recipe, multiply the standard time by 3 and cook at 250° – 275°F (125° – 135°C)

HELPFUL HINTS

1. To serve directly from the Roaster Oven set the temperature at 225° – 250°F (110 ° – 125°C) to keep food hot during serving.
2. The Roaster Oven is ideal for cooking large quantities of stew, soup, baked beans etc.

CARE AND CLEANING

1. After use, turn the Temperature Control Knob to 'Off', unplug unit from the outlet and allow the Roaster Oven to cool.
2. Wash the Cover, Rack and Removable Cooking Pan in warm soapy water. **DO NOT** place in the dishwasher. Remove any stuck on food with a non-abrasive cleaning pad.
DO NOT USE ABRASIVE CLEANSERS OR STEEL WOOL PADS.
3. Wipe the interior and exterior of the Roaster Oven base with a damp cloth. **DO NOT IMMERSE THE ROASTER OVEN BASE IN WATER OR ANY OTHER LIQUID.**

RECIPES**Baked Beans**

200 fl. oz. (5.5L)	Beans in tomato sauce
1 cup (250 ml)	Brown sugar
4 cups (1L)	Ketchup
1/2 cup (125 ml)	Dry onion flakes

Combine all ingredients in Removable Cooking Pan. Bake at 350° (180°C) for approximately 2 hours or until bubbling. Stir halfway through cooking time. Serves 50.

Chili Meatball Supper

6 cups (1.5 L)	Onions, chopped
6 large	Green peppers, chopped
6 cans	Kidney beans, drained 15 oz./ 454 ml. each
6 cans	Tomatoes, diced, 16 oz. / 480 ml. each
4 cans	Whole kernel corn, 12 oz. / 360 ml. each
2 cans	Tomato sauce, 15 oz. / 454 ml. each
1/4 cup (60 ml)	Chili powder
6	Bay leaves
2 tbsp.	Salt
144	Meatballs (see recipe below)

Combine onion, green pepper, kidney beans, tomatoes, corn (undrained), tomato sauce, chili powder, bay leaves and salt. Bring to boiling. Stir in meatballs. Cover and simmer until meatballs are heated through, approximately 45 minutes. Stir occasionally during cooking.

Oven-Baked Meatballs

6	Eggs, beaten
1/2 cup (125 ml)	Milk
6 cups (1500 ml)	Bread crumbs
1 cup (250 ml)	Onion, finely chopped
4 tsp. (20 ml)	Salt
6 lbs. (2.7 kgs.)	Ground beef

Combine eggs and milk in a large bowl. Stir in crumbs, onion and salt. Add meat; mix well. Chill. Shape meat into 1" (2.5 cm) balls. Makes about 144. Heat roaster to 375° F (190°C). Bake meatballs in a single layer in the Cooking Pan, until cooked through. Cool. Package in freezer bags and place in the freezer.

Beef Stew

10 lbs. (4.5 kgs.)	Stewing beef
	Cooking oil for browning
3 tbsp. (45 ml)	Salt
2 tsp. (10 ml)	Pepper
	Water
4 lbs. (3.6 kgs)	Frozen sliced carrots
3	Spanish onions, cut in chunks
2 lbs. (1.8 kgs)	Frozen peas

Place cooking oil in bottom of pan. Add 1/2 of stewing beef. Cover and cook at 425°F (220°C) until browned. Set aside and brown second half of stewing beef and onions. Return browned beef to roaster and add water up to the top of the beef. Add salt and pepper. Cover and bring to a boil at (450°F / 230°C). Simmer at 350°F (175°C) for 1-1/2 hours or until meat is tender. Add more water if necessary. Cook carrots and peas according to package directions then add to the roaster. Stir to distribute evenly. Serve immediately or leave on warm until ready to serve.

Roast Chicken

2	Roasting chickens, 5 lbs.(2.2 kgs.) each
1 tsp. (5 ml)	Dried thyme
1 tsp. (5 ml)	Salt
2 tsps. (10 ml)	Butter or margarine
2	Onions, diced
2	Celery stalks, diced
1/3 cup (85 ml)	Honey
1/4 cup (60 ml)	Spicy brown mustard

Sprinkle the inside of cavities with thyme and salt. Mix margarine with onions and celery and place inside cavity of chickens. Mix honey and mustard together in a small bowl. Brush the mixture on the outside of the chicken. Place chicken on rack and roast at 425°F (220°C) for 20 minutes. Decrease temperature to 375°F (190°C) and brush occasionally with remaining honey and mustard mixture. Roast until internal temperature is 195°F (90°C).

Corned Beef and Cabbage

1	Corned beef brisket, 6 lbs. (2.7 kgs.)
12	Potatoes, medium size, halved
3/4 tsp. (4 ml)	Black pepper
3/4 tsp. (4 ml)	Rosemary
2	Bay leaves
3	Cloves, whole
9	Carrots, large, peeled and cut in chunks
6	Onions, small, peeled
3	Cabbages, small, cut into quarters
	Hot water

Combine pepper and rosemary and rub onto outside of brisket. Place brisket in Cooking Pan. Add enough water so the brisket is half covered. Add bay leaves and cloves. Cover and cook at 400°F (205°C) until boiling. Reduce temperature to 250°F (125°C). Add carrots, onions and cabbage. Cover and cook for 3 to 4 hours or until meat is tender.

Corn on the Cob

12	Ears of corn, shucked
	Water

Add approximately 1/2" (12 mm) water into the Cooking Pan. Cover and heat at 400°F (205°C) until boiling. Set corn on rack. Hold rack by the handles and carefully add to the roaster. Steam for 25 to 30 minutes or until tender.

Apple Spice Cake

1-3/4 cups (430 ml)	All-purpose flour
2-1/2 tsp. (13 ml)	Baking Powder
1/2 tsp. (3 ml)	Salt
1 tsp. (5 ml)	Cinnamon
1/2 tsp. (3 ml)	Nutmeg
1/2 cup (125 ml)	Shortening
1-1/4 cups (310 ml)	Brown sugar, lightly packed
2	Eggs
1/2 cup (125 ml)	Applesauce
2/3 cup (170 ml)	Milk

Preheat oven to 350°F (175°C). Grease an 8" square pan. Sift together flour, baking powder, salt, cinnamon and nutmeg. Cream shortening, then beat in brown sugar. Blend in eggs until mixture is light and fluffy. Add sifted dry ingredients to creamed mixture alternately with a mixture of applesauce and milk making 3 dry and 2 liquid additions. Combine lightly after each addition. Turn into prepared pan.

Bake in preheated oven for approximately 50 minutes or until cake springs back when lightly touched. Remove from oven and let cool for 5 – 10 minutes before removing from pan.

A short supply cord is provided to reduce the hazards of becoming entangled in or tripping over a long cord. Extension cords may be used if care is exercised in their use. If an extension cord is used, the marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance. If the appliance is of the grounded type, the extension cord should be a grounded 3-wire cord. The extension cord should be arranged so that it will not drape over the counter top or table top, where it can be pulled on by children or tripped over.

LIMITED WARRANTY

****The original sales receipt is the only acceptable proof of purchase****

Salton Canada warrants that this appliance shall be free from defects in material and workmanship for a period of five (5) years from the date of original purchase. Salton Canada, at its sole discretion during this warranty period, will repair or replace a defective product or issue a refund. Any refund to the purchaser will be at a pro-rated value based on the remaining period of the warranty. All liability is limited to the amount of the purchase price. This warranty covers normal domestic usage and does not cover damage which occurs in shipment or failure which results from alteration, accident, misuse, abuse, glass breakage, neglect, improper maintenance, use contrary to the operating instructions or commercial use. This warranty is not available to retailers or other commercial purchasers or owners.

This warranty does not include the cost of shipping, which is to be borne by the customer.

TO OBTAIN PROMPT WARRANTY SERVICE:

Contact one of our many Service Centers found on our website
www.salton.com/customer-care

or

Securely package and return the appliance to us. Please enclose:

- Original proof of purchase
- The completed form below with a \$12.50 Return Shipping & Handling fee – either a cheque, money order or credit card (A personal cheque will delay return shipping by 2-3 weeks)

For added protection, we suggest that you use an insured delivery service with tracking information when returning your product. Salton Canada will not be held responsible for in-transit damage or for packages that are not received.

This warranty does not include the cost of shipping, which is to be borne by the customer.

.....

Name _____

Address _____

City _____ Prov/State _____ Postal/Zip Code _____

Daytime Phone No. _____ Email _____

Product defect: _____

Type of payment Cheque/Money Order Visa MasterCard

Name on card _____ Expiry Date _____ CSV No _____

Card No. _____

To contact our Customer Service Department:

SALTON CANADA
81A Brunswick,
Dollard-des-Ormeaux, Quebec H9B 2J5
Canada

Telephone: 514-685-3660 (Ext. 226)
E-mail: service@salton.com
Fax: 514-685-8300
www.salton.com