



salton[®]
sandwich
maker



Instruction Booklet

Model SM1068

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following

1. Read all instructions.
2. **DO NOT** touch hot surfaces. Use handles or knobs.
3. To protect against electrical hazards, **DO NOT** immerse cord, plugs, or the appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children. Do not allow children to play with the appliance.
5. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
6. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
7. **DO NOT** operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to Salton for examination, repair or adjustment. All servicing other than cleaning should be performed by an authorized service representative. See Warranty.
8. The use of accessories or attachments not recommended by Salton may cause hazards.
9. Do not use outdoors.
10. **DO NOT** let cord hang over edge of table or counter, or touch hot surfaces.
11. **DO NOT** place on or near a hot gas or electric burner, or in a heated oven.
12. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
13. **DO NOT** move the appliance when it is still hot.
14. Prior to connecting or disconnecting plug from wall outlet, turn any control to 'Off'.
15. Always unplug appliance immediately after using. Allow to cool before cleaning and storing.
16. Always place appliance on a heat resistant surface.
17. **CAUTION:** This appliance generates heat during use. Proper precautions must be taken to prevent the risk of burns, fires or other damage to property caused by touching the sides or top while in use or during cooling.

18. **DO NOT** use appliance for other than intended use.
19. **DO NOT** leave appliance unattended while in use.
20. **DO NOT** touch the metallic parts of the unit while the appliance is operating. These can become very hot.

SAVE THESE INSTRUCTIONS


HOUSEHOLD USE ONLY

GROUNDING PLUG

To reduce the risk of electric shock this appliance has a grounded plug (2 blades and 1 pin). If the plug does not fit fully into the electrical outlet contact a qualified electrician. Do not modify the plug in any way or use an adaptor.

DESCRIPTION OF PARTS

1. Lid
2. Base
3. Cooking Plates
4. Carrying Handles
5. Locking Clip
6. Indicator Lights
 - Red Power Light
 - Green Ready Light*(not shown)*



BEFORE FIRST USE

1. Read all instructions carefully and keep them for future reference.
2. Remove all packaging.
3. Clean the Cooking Plates by wiping with a sponge or cloth dampened in warm water. **DO NOT IMMERSE THE UNIT AND DO NOT RUN WATER DIRECTLY ONTO THE COOKING SURFACE.**
4. Dry with a cloth or paper towel.

HOW TO USE

1. Plug unit into a 120V AC outlet. The red 'Power' Indicator Light will come on.
2. Close the lid until the unit has preheated and the Green 'Ready' Indicator Light comes on.
3. Open the lid and place a slice of bread on the bottom half of the Cooking Plate. (If you are using buttered bread, place the buttered side against the Cooking Plates.) Place filling on the bread pressing down to fill the Cooking Plate cavity. Cover with a slice of bread.
4. Close lid carefully and lock. Cooking time should be 3-5 minutes. Exact cooking time depends on your taste.
5. When sandwiches are cooked, remove with a wooden or plastic spatula. Never touch the Cooking Plates with sharp, pointed or metal utensils.
6. To make additional batches follow steps 2 – 5 or unplug the unit if you are finished cooking.
7. **NOTE:** All parts of the unit, except the handle, will be hot during and after cooking. Do not touch any parts of the unit except the handle until the unit has cooled.

HELPFUL HINTS

- Always preheat the Sandwich Maker before using.
- Select bread that will fit the Cooking Plates.
- It is not necessary to butter bread.
- Do not use processed cheese, it melts too quickly.
- Use approximately 1/3 cup (85 ml) of filling for each sandwich.
- When using sweet filling a teaspoon of sugar on the buttered side of the bread will add flavor and make the outside of the sandwiches crispier.
- Raisin bread or other sweet breads brown quickly so adjust cooking time accordingly.
- Pastry may be used instead of bread.

CARE AND CLEANING

1. Unplug the Sandwich Maker and allow it to cool.
2. Wipe the Cooking Plates with paper towels or a soft cloth. **DO NOT**

IMMERSE THE UNIT AND DO NOT RUN WATER DIRECTLY ONTO THE COOKING SURFACE. If some of the filling has adhered to the Cooking Plates, pour a small amount of cooking oil onto the baked-on food and allow to stand for 5 to 10 minutes. Wipe with paper towels.

3. Wipe the outside of the Sandwich Maker with a soft cloth dampened in warm soapy water.
4. Dry with a soft cloth.
5. All servicing, other than cleaning, should be performed by an authorized service representative. See Warranty section.

RECIPES

Garlic Butter

- | | |
|----------------|--------------------------------|
| 4 oz. (125 ml) | butter, softened |
| 1 | clove garlic, crushed |
| | Salt and freshly ground pepper |

Combine all ingredients until smooth.

Herb Butter

- | | |
|------------------|---------------------------------|
| 1/2 cup (125 ml) | butter, softened |
| 1 tsp. (5 ml) | parsley, chopped |
| 1 tsp. (5 ml) | chives, chopped |
| 1/2 tsp. (3 ml) | rosemary, chopped |
| | Salt and freshly ground pepper. |

Combine all ingredients until smooth.

Lemon Butter

- | | |
|------------------|------------------------|
| 1/2 cup (125 ml) | butter, softened |
| 2 tsp. (10 ml) | lemon juice |
| 1 tsp. (5 ml) | grated lemon rind |
| | dash of cayenne pepper |

Combine all ingredients until smooth.

Ham/Cheese/Tomato Sandwich

- 4 slices bread, buttered on one side
- 4 slices cheese (not processed cheese)
- 2 slices tomato, cut in half
- 1/4 cup (60 ml) chopped ham

Preheat Sandwich Maker. Place 2 slices of bread, buttered side down on the Cooking Plates. Cover each piece of bread with 2 slices of cheese, 2 pieces of tomato and 1/2 of the chopped ham. Cover with remaining bread, buttered side up. Close and lock Lid. Cook approximately 3 minutes.

Mushroom Pizza

- 4 slices bread, buttered one side
- 2 tsp. (10 ml) pizza sauce
- 4 canned whole mushrooms, sliced
- 1/4 cup (60 ml) grated mozzarella cheese

Preheat Sandwich Maker. Place 2 slices of bread, buttered side down on Cooking Plates. Make 4 small pockets by pressing bread down with the back of a spoon. Fill cavity with pizza sauce, mushrooms and cheese. Top with remaining 2 slices of bread. Close and lock Lid. Cook for approximately 3 minutes.

Chicken Sandwich

- 4 slices of bread, one side buttered with garlic butter
- 2 oz. (50 g) cooked chicken, sliced or small cubes
- 1/4 green pepper, sliced
- 2 mushrooms, sliced

Preheat Sandwich Maker. Place 2 slices of bread, buttered side down on the Cooking Plates. Spread chicken, green pepper and mushrooms over bread and cover with remaining slice of bread. Close and lock Lid. Cook for approximately 3 minutes.

Tuna with Cheese

- 1/2 can tuna, drained
- 1-1/2 tbsp. (22 ml) mayonnaise
- 1 tsp. (5 ml) sweet mixed pickle, chopped
- 4 slices bread, buttered one side
- 2 slices of cheese (not processed cheese)

Preheat Sandwich Maker. Combine tuna, mayonnaise and pickle. Divide tuna mixture evenly on unbuttered side of 2 slices of bread. Top with tomato slices and cheese and remaining bread. Place sandwiches on Cooking Plates. Close and lock Lid. Cook for approximately 3 minutes.

Blueberry French Toast

- 2 eggs
- 2 tbsp. (30 ml) milk
- 4 slices bread
- 1/4 cup (60 ml) blueberries
- 1 tsp. (5 ml) sugar

Preheat Sandwich Maker. Beat eggs and milk together. Dip bread in the egg mixture. Brush a small amount of butter on the Cooking Plates. Place 2 slices of bread onto the Cooking Plates. Make a small cavity by pressing bread down with the back of a spoon. Distribute blueberries evenly in each cavity. Cover with remaining bread and sprinkle with sugar. Close and lock Lid. Cook for approximately 4 minutes.

Apple/Cinnamon Treats

- 4 slices of sweet bread,
buttered one side and sprinkled with sugar
- 1/2 cup (125 ml) apple pie filling
dash of cinnamon

Preheat Sandwich Maker. Place 2 slices of bread, buttered side down on the Cooking Plates. Distribute the pie filling evenly between the 4 cavities. Sprinkle with cinnamon. Cover with remaining 2 slices of bread. Close and lock Lid. Cook for approximately 3 minutes.

A short supply cord is provided to reduce the hazards of becoming entangled in or tripping over a long cord. Extension cords may be used if care is exercised in their use. If an extension cord is used, the marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance. If the appliance is of the grounded type, the extension cord should be a grounded 3-wire cord. The extension cord should be arranged so that it will not drape over the counter top or table top, where it can be pulled on by children or tripped over.

LIMITED WARRANTY

****The original sales receipt is the only acceptable proof of purchase****

Salton Canada warrants that this appliance shall be free from defects in material and workmanship for a period of two (2) years from the date of original purchase. Salton Canada, at its sole discretion during this warranty period, will repair or replace a defective product or issue a refund. Any refund to the purchaser will be at a pro-rated value based on the remaining period of the warranty. All liability is limited to the amount of the purchase price. This warranty covers normal domestic usage and does not cover damage which occurs in shipment or failure which results from alteration, accident, misuse, abuse, glass breakage, neglect, improper maintenance, use contrary to the operating instructions or commercial use. This warranty is not available to retailers or other commercial purchasers or owners.

This warranty does not include the cost of shipping, which is to be borne by the customer.

TO OBTAIN PROMPT WARRANTY SERVICE:

Contact one of our many Service Centers found on our website www.salton.com/customer-care

or

Securely package and return the appliance to us. Please enclose:

- Original proof of purchase
- The completed form below with a \$12.50 Return Shipping & Handling fee – either a cheque, money order or credit card (A personal cheque will delay return shipping by 2-3 weeks)

For added protection, we suggest that you use an insured delivery service with tracking information when returning your product. Salton Canada will not be held responsible for in-transit damage or for packages that are not received.

This warranty does not include the cost of shipping, which is to be borne by the customer.

.....
Name _____

Address _____

City _____ Prov/State _____ Postal/Zip Code _____

Daytime Phone No. _____ Email _____

Product defect: _____

Type of payment Cheque/Money Order Visa MasterCard

Name on card _____ Expiry Date _____ CSV No _____

Card No. _____

To contact our Customer Service Department:

SALTON CANADA
81A Brunswick,
Dollard-des-Ormeaux, Quebec H9B 2J5
Canada

Telephone: 514-685-3660 (Ext. 226)
E-mail: service@salton.com
Fax: 514-685-8300
www.salton.com