



salton®
multi-cooker



Instruction Booklet

Model MP1206

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. **DO NOT** touch hot surfaces. Use handles or knobs.
3. To protect against electrical hazards, **DO NOT** immerse cord, plugs, or the appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. **DO NOT** operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to Salton for examination, repair or adjustment. See Warranty section.
7. The use of accessories or attachments not recommended by Salton may cause hazards.
8. **DO NOT** use outdoors.
9. **DO NOT** let cord hang over edge of table or counter, or touch hot surfaces.
10. **DO NOT** place on or near a hot gas or electric burner, or in a heated oven.
11. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'OFF', then remove plug from wall outlet.
12. Extreme caution must be used when moving an appliance containing hot liquids.
13. This appliance is for Household Use Only. Do not use appliance for other than intended use.
14. **DO NOT** leave unit unattended while in use.

SAVE THESE INSTRUCTIONS
HOUSEHOLD USE ONLY

GROUNDING PLUG

To reduce the risk of electric shock this appliance has a grounded plug (2 blades and 1 pin). If the plug does not fit fully into the electrical outlet contact a qualified electrician. **DO NOT** modify the plug in any way or use an adaptor.

BEFORE FIRST USE

1. Wash the inside of the Multi-Pot with warm soapy water.
2. **DO NOT IMMERSE IN WATER OR ANY OTHER LIQUID.**

HOW TO USE

To Boil Water

1. Fill the Multi-Pot with a maximum of 4 cups (1L) of water.
Note: The 'MAX' fill line on the inside of the unit is for heating food.
2. Close Cover.
3. Place unit on a level heat resistant surface and plug unit into a 120 volt A.C. outlet.
4. Turn the temperature dial to BOIL.
5. Once water has boiled, unplug before emptying water. **DO NOT ALLOW TO BOIL DRY. NOTE:** Keep cover closed to avoid spilling.

To Heat Canned Foods

1. Place food in unit up to a maximum of 3 cups (750 ml). The maximum fill line is marked on the inside of the Multi-Pot.
2. When heating foods that are mostly liquid (i.e. soups) turn the dial to a medium setting, for thicker foods (i.e. stews) turn the temperature dial to a low setting.
3. Allow food to heat, stirring frequently. **NOTE: DO NOT** use utensils that could scratch the non-stick cooking surface.
4. Unplug before emptying.

HELPFUL HINTS

1. Note the following settings:
 - Warm – 1st position
 - Low - 2nd and 3rd position
 - Medium - 4th and 5th position
 - High- 6th and 7th position
 - Boil - 7th position
2. Always open the cover away from you to avoid escaping steam.
3. Stir food frequently during cooking/heating.

CARE AND CLEANING

1. Allow the unit to cool.
2. **NEVER IMMERSE UNIT IN WATER OR ANY OTHER LIQUID.**
4. Wash the inside of the unit with warm soapy water and a sponge or soft cloth. Empty, rinse and dry. If necessary, use a nylon scouring pad, safe for non-stick surfaces.
5. Wipe the outside of the unit with a damp cloth.
6. **DO NOT** use abrasive cleansers on any part of the unit.

A short supply cord is provided to reduce the hazards of becoming entangled in or tripping over a long cord. Extension cords may be used if care is exercised in their use. If an extension cord is used, the marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance. If the appliance is of the grounded type, the extension cord should be a grounded 3-wire cord. The extension cord should be arranged so that it will not drape over the counter top or table top, where it can be pulled on by children or tripped over.

LIMITED WARRANTY

The original sales receipt is the only acceptable proof of purchase

Salton Canada warrants that this appliance shall be free from defects in material and workmanship for a period of two (2) years from the date of original purchase. Salton Canada, at its sole discretion during this warranty period, will repair or replace a defective product or issue a refund. Any refund to the purchaser will be at a pro-rated value based on the remaining period of the warranty. All liability is limited to the amount of the purchase price. This warranty covers normal domestic usage and does not cover damage which occurs in shipment or failure which results from alteration, accident, misuse, abuse, glass breakage, neglect, improper maintenance, use contrary to the operating instructions or commercial use. This warranty is not available to retailers or other commercial purchasers or owners.

This warranty does not include the cost of shipping, which is to be borne by the customer.

TO OBTAIN PROMPT WARRANTY SERVICE:

Contact one of our many Service Centers found on our website
www.salton.com/customer-care

or

Securely package and return the appliance to us. Please enclose:

- Original proof of purchase
- The completed form below with a \$12.50 Return Shipping & Handling fee – either a cheque, money order or credit card (A personal cheque will delay return shipping by 2-3 weeks)

For added protection, we suggest that you use an insured delivery service with tracking information when returning your product. Salton Canada will not be held responsible for in-transit damage or for packages that are not received.

This warranty does not include the cost of shipping, which is to be borne by the customer.

Name _____

Address _____

City _____ Prov/State _____ Postal/Zip Code _____

Daytime Phone No. _____ Email _____

Product defect: _____

Type of payment Cheque/Money Order Visa MasterCard

Name on card _____ Expiry Date _____ CSV No _____

Card No. _____

To contact our Customer Service Department:

SALTON CANADA
81A Brunswick,
Dollard-des-Ormeaux, Quebec H9B 2J5
Canada

Telephone: 514-685-3660 (Ext. 226)
E-mail: service@salton.com
Fax: 514-685-8300
www.salton.com