

iShave
salton®




Instruction Booklet
Model SP1410

BEFORE FIRST USE

1. Read all instructions.
2. Before using for the first time or if the iShave has not been used for a long time, ensure that it is fully charged, 6 – 8 hours.
3. The iShave is designed to be recharged in any standard USB charging socket. The standard voltage is DC5V 2W.
4. Never clean the iShave with water.
5. To minimize the risk of electric shock do not plug or unplug the iShave with wet hands.


DESCRIPTION OF PARTS

1. Protective Cover
2. Foil and Hood
3. Blade
4. Body
5. On/Off Switch
6. Charging Indicator Light
7. USB Charger Plug
8. Cleaning Brush



HOW TO RECHARGE THE iSHAVE

1. To promote the shelf life of the iShave, it is highly recommended to recharge the iShave only after the battery has run down completely.
2. If the battery is not completely run down and you want to charge the iShave, switch it to the On position and allow it to run until completely run down.
3. Check the power supply before recharging the iShave. It is designed to be recharged in any standard USB charging socket. The standard voltage is DC5V 2W.
4. The iShave should be recharged in temperatures between 5 – 35°C (41 – 95°F).
5. Ensure that the iShave and its power socket are completely dry before recharging.
6. Turn the On/Off switch to the Off position. Swivel out the USB charging adapter and insert it into any standard USB port. The Indicator Light will light up when the iShave is being recharged.



HOW TO USE

1. Always clean your face thoroughly before using the iShave. This will give you better shaving performance.
2. Remove the Protective Cover and push the On/Off switch upward to turn on the iShave.
3. Stretch your skin with your free hand and hold the iShave at a right angle to the skin. Gently shave over the desired area.
4. When shaving do not apply too much pressure to avoid injury to your skin.
NOTE: Your skin may require a little time to get used to a new shaving method.
5. After you have finished shaving, turn off the iShave and replace the cover.



CARE AND CLEANING


Regular Maintenance

1. Regular cleaning will keep the iShave in good condition and maintain its cutting performance.
2. Unplug and turn the On/Off Switch to the Off position.
3. Remove the Protective Cover.
4. Lift the Foil with Hood by each side and lift off. (See the 'Replacing the Foil and Hood' section)

5. Gently clean the Foil and Hood and the Inner Blades with the Cleaning Brush supplied with the iShave.
6. Reassemble by replacing the Foil and Hood by lining up the Hood with the outside edges of the Shaver. Press down gently. You will hear both sides snap into place.
7. **NEVER CLEAN THE ISHAVE WITH WATER.**


Replacing the Foil and Hood

1. Use only genuine parts that are available at Salton Canada .
2. The On/Off Switch must be in the Off position before replacing the Foil and Hood or the Inner Blades.
3. To remove the Foil and Hood pull up on each side and lift off.
4. Reassemble by lining up the Foil and Hood with the outside edges of the Shaver. Press down gently. You will hear both sides snap into place.




Replacing the Inner Blades

1. Remove the Foil with Hood. (See above section)
2. Hold the Blade firmly at each end and gently pull upward to release the Blade from the Shaver.



3. Hold the new Blade firmly at both ends and insert the white plastic tip into the hole in the iShave until it snaps into place.



4. Replace the Foil and Hood. (See above section)

TROUBLESHOOTING

Problem	Solution
Poor shaving results	Replace the Blade and Foil/Hood
Weak or slow blade rotation or shorter time between charges	Remove the Foil and Hood and clean the blade with the Cleaning Brush supplied with the iShave.
No indicator light on or unable to recharge.	Check if the On/Off switch is turned off. The iShave will not recharge with the On/Off switch in the On position.

LIMITED WARRANTY

****The original sales receipt is the only acceptable proof of purchase****

Salton Canada warrants that this appliance shall be free from defects in material and workmanship for a period of one (1) year from the date of original purchase. Salton Canada, at its sole discretion during this warranty period, will repair or replace a defective product or issue a refund. Any refund to the purchaser will be at a pro-rated value based on the remaining period of the warranty. All liability is limited to the amount of the purchase price.

This warranty covers normal domestic usage and does not cover damage which occurs in shipment or failure which results from alteration, accident, misuse, abuse, glass breakage, neglect, improper maintenance, use contrary to the operating instructions or commercial use. This warranty is not available to retailers or other commercial purchasers or owners.

This warranty does not include the cost of shipping, which is to be borne by the customer. This warranty does not cover the Blade or the Foil and Hood.

TO OBTAIN PROMPT WARRANTY SERVICE:

Contact one of our many Service Centers found on our website www.salton.com/customer-care

or

Securely package and return the appliance to us.
Please enclose:

- Original proof of purchase
- The completed form below with a \$7.50 Return Shipping & Handling fee – either a cheque, money order or credit card (A personal cheque will delay return shipping by 2-3 weeks)

For added protection, we suggest that you use an insured delivery service with tracking information when returning your product. Salton Canada will not be held responsible for in-transit damage or for packages that are not received.

Name

Address

City

Prov/State

Postal/Zip Code

Daytime Phone No.

Email

Product defect:

Type of payment

Cheque/Money Order

Visa

MasterCard

Name on card

Expiry Date

CSV No

Card No.

To contact our Customer Service Department:

SALTON CANADA

81A Brunswick,

Dollard-des-Ormeaux, Quebec H9B 2J5

Canada

Telephone: 514-685-3660 (Ext. 226)

E-mail: service@salton.com

Fax: 514-685-8300

www.salton.com