



**salton®**

**electric  
gravy warmer**



**Instruction Booklet**

Model: SMW1508

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. Do not use outdoors.
3. Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure that they do not play with the appliance.
4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
5. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to Salton for examination, repair or adjustment. See Warranty.
6. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning the appliance.
7. The use of accessories or attachments not recommended by Salton may cause hazards.
8. Do not let cord hang over edge of table or counter or touch hot surfaces.
9. Do not place on or near a hot gas or electric burner or in a heated oven.
10. Do not touch hot surfaces. Use handles or knobs.
11. To protect against electrical hazards, do not immerse cord, plugs or the Warming Base in water or any other liquid.
12. All servicing, other than cleaning, should be performed by an authorized service representative. See Warranty section.
13. Extreme caution must be used when moving an appliance containing hot liquids.
14. Always attach plug to appliance first then plug into the wall outlet. To disconnect remove the plug from the wall outlet and then remove other end from appliance.
15. Do not use appliance for other than its intended use.

16. Do not leave unit unattended while in use.

17. **CAUTION:** The warming surface will remain warm for several minutes after the unit is unplugged.

## SAVE THESE INSTRUCTIONS


### HOUSEHOLD USE ONLY

#### POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

#### DESCRIPTION OF PARTS

1. Gravy Boat
2. Warming Base
3. Base Heating Surface
4. Indicator Light
5. Detachable Cord



#### BEFORE FIRST USE

1. Remove all packaging materials.
2. Wash the gravy boat with warm soapy water. Rinse and dry.
3. Wipe the warming base with a clean damp cloth.  
Do not use abrasive cleaner or scouring pads.

**NEVER IMMERSE THE BASE IN WATER OR ANY OTHER LIQUID.**

## **HOW TO USE**

1. Place the Warming Base on a level, heat and stain resistant surface.
2. Connect the power cord to the Warming Base. Plug into the 120 volt wall outlet.
3. Pour the hot gravy into the Gravy Boat.
4. Place the Gravy Boat on the Base Heating Surface.
5. To bring the Gravy Warmer to the table, unplug from the outlet then remove the detachable cord from the Base.

## **IMPORTANT NOTES:**

- The gravy, sauce or syrup should be at the ideal serving temperature when put into the gravy boat. The Gravy Warmer is not designed to heat cold gravy, sauce or syrup.
- This appliance is only intended to be used with the gravy boat that came with the Warming Base.

## **CARE AND CLEANING**

1. Always unplug the appliance and let it cool before cleaning.
2. The Gravy Boat can be washed in warm soapy water or placed in the dishwasher.
3. Clean the Warming Base by wiping with a cloth dampened in warm soapy water.
4. Dry thoroughly.
5. NEVER immerse the Warming Base in water or any other liquid.
6. NEVER use abrasive cleaning products.
7. All servicing, other than cleaning, should be performed by an authorized service representative. See Warranty section.

A short supply cord is provided to reduce the hazards of becoming entangled in or tripping over a long cord. Extension cords may be used if care is exercised in their use. If an extension cord is used, the marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance. If the appliance is of the grounded type, the extension cord should be a grounded 3-wire cord. The extension cord should be arranged so that it will not drape over the counter top or table top, where it can be pulled on by children or tripped over.

#### **LIMITED WARRANTY**

**\*\*The original sales receipt is the only acceptable proof of purchase\*\***

Salton Canada warrants that this appliance shall be free from defects in material and workmanship for a period of five (5) years from the date of original purchase. Salton Canada, at its sole discretion during this warranty period, will repair or replace a defective product or issue a refund. Any refund to the purchaser will be at a pro-rated value based on the remaining period of the warranty. All liability is limited to the amount of the purchase price. This warranty covers normal domestic usage and does not cover damage which occurs in shipment or failure which results from alteration, accident, misuse, abuse, glass breakage, neglect, improper maintenance, use contrary to the operating instructions or commercial use. This warranty is not available to retailers or other commercial purchasers or owners.

This warranty does not include the cost of shipping, which is to be borne by the customer.

**TO OBTAIN PROMPT WARRANTY SERVICE:**

Contact one of our many Service Centers found on our website  
www.salton.com/customer-care

or

Securely package and return the appliance to us. Please enclose:

- Original proof of purchase
- The completed form below with a \$12.50 Return Shipping & Handling fee – either a cheque, money order or credit card (A personal cheque will delay return shipping by 2-3 weeks)

For added protection, we suggest that you use an insured delivery service with tracking information when returning your product. Salton Canada will not be held responsible for in-transit damage or for packages that are not received.

This warranty does not include the cost of shipping, which is to be borne by the customer.

.....

Name \_\_\_\_\_

Address \_\_\_\_\_

City \_\_\_\_\_ Prov/State \_\_\_\_\_ Postal/Zip Code \_\_\_\_\_

Daytime Phone No. \_\_\_\_\_ Email \_\_\_\_\_

Product defect: \_\_\_\_\_

Type of payment      Cheque/Money Order       Visa       MasterCard

Name on card \_\_\_\_\_ Expiry Date \_\_\_\_\_ CSV No \_\_\_\_\_

Card No. \_\_\_\_\_

To contact our Customer Service Department:

SALTON CANADA  
81A Brunswick,  
Dollard-des-Ormeaux, Quebec H9B 2J5  
Canada

Telephone: 514-685-3660 (Ext. 226)  
E-mail: service@salton.com  
Fax: 514-685-8300  
www.salton.com