



**salton®**

**cordless  
lazy susan  
HOTRAY**



## **Instruction Booklet**

Model: WT1564

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical hazards, do not immerse cord, plugs, or the appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure that they do not play with the appliance.
5. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
6. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
7. DO NOT operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the manufacturer for examination, repair or electrical or mechanical adjustment. All servicing, other than cleaning, should be performed by an authorized service representative. See Warranty section.
8. The use of accessories or attachments not recommended by the manufacturer may cause hazards.
9. Do not use outdoors.
10. Do not let cord hang over edge of table or counter, or touch hot surfaces.
11. Do not place on or near a hot gas or electric burner, or in a heated oven.
12. Extreme caution must be used when moving an appliance containing hot liquids.
13. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, remove plug from wall outlet and then remove other end from appliance.

14. This appliance is for Household Use Only. Do not use appliance for other than its intended use.

15. Do not leave unit unattended while in use.

## **SAVE THESE INSTRUCTIONS HOUSEHOLD USE ONLY**

### **GROUNDING PLUG**

To reduce the risk of electric shock this appliance has a grounded plug. (2 blades and 1 pin) If the plug does not fit fully into the electrical outlet contact a qualified electrician. Do not modify the plug in any way or use an adaptor.

### **BEFORE FIRST USE**

Wipe the surface of the Hotray® with a damp cloth; dry thoroughly.

### **HOW TO USE**

1. Connect the power cord to the Warming Tray and then plug into a 120 volt A.C. outlet.
2. The Hotray® will take approximately 8 minutes to reach the maximum temperature. After 8 minutes the Hotray® can be left plugged in or unplugged from the wall outlet. If it is plugged into the outlet, the thermostat will cycle on and off automatically to protect against overheating. If unplugged the Warming Tray will continue to give off heat for approximately 60 minutes.
3. The red 'power' indicator light will remain 'On' as long as the Hotray® is plugged in. The green 'ready' light will come on when the tray has preheated. If the unit is left plugged in, the green light will cycle on and off as the unit maintains the correct temperature.
4. Rotate the Hotray® by the 2 handles on the sides or place your fingers underneath the edge of the black base.

### **IMPORTANT NOTES:**

- Never put food directly on the Hotray, use cookware, casseroles or serving dishes.
- The stainless steel will be hot. DO NOT USE to rotate the Lazy Susan.
- Porcelain and china dishes may cause scratches. Place dishes carefully on stainless steel heating surface so they do not scratch.

## **HELPFUL HINTS**

- Ensure that the Hotray® is always placed on a flat and sturdy surface.
- Covered crockery dishes with a flat base and edges that are not too high keep food the warmest.

## **CLEANING**

1. Always unplug the appliance and let it cool before cleaning.
2. Clean the Hotray® by wiping with a cloth dampened in warm soapy water. Dry thoroughly.
3. NEVER immerse the Hotray® in water or any other liquid.  
NEVER use abrasive cleaning products, bleach or alcohol.

A short supply cord is provided to reduce the hazards of becoming entangled in or tripping over a long cord. Extension cords may be used if care is exercised in their use. If an extension cord is used, the marked electrical rating of the detachable power-supply cord or extension cord should be at least as great as the electrical rating of the appliance. If the appliance is of the grounded type, the extension cord should be a grounded 3-wire cord. The extension cord should be arranged so that it will not drape over the counter top or table top, where it can be pulled on by children or tripped over.

#### **LIMITED WARRANTY**

**\*\*The original sales receipt is the only acceptable proof of purchase\*\***

Salton Canada warrants that this appliance shall be free from defects in material and workmanship for a period of five (5) years from the date of original purchase. Salton Canada, at its sole discretion during this warranty period, will repair or replace a defective product or issue a refund. Any refund to the purchaser will be at a pro-rated value based on the remaining period of the warranty. All liability is limited to the amount of the purchase price. This warranty covers normal domestic usage and does not cover damage which occurs in shipment or failure which results from alteration, accident, misuse, abuse, glass breakage, neglect, improper maintenance, use contrary to the operating instructions or commercial use. This warranty is not available to retailers or other commercial purchasers or owners.

This warranty does not include the cost of shipping, which is to be borne by the customer.

**TO OBTAIN PROMPT WARRANTY SERVICE:**

Contact one of our many Service Centers found on our website  
[www.salton.com/customer-care](http://www.salton.com/customer-care)

or

Securely package and return the appliance to us. Please enclose:

- Original proof of purchase
- The completed form below with a \$12.50 Return Shipping & Handling fee – either a cheque, money order or credit card (A personal cheque will delay return shipping by 2-3 weeks)

For added protection, we suggest that you use an insured delivery service with tracking information when returning your product. Salton Canada will not be held responsible for in-transit damage or for packages that are not received.

This warranty does not include the cost of shipping, which is to be borne by the customer.

.....

Name \_\_\_\_\_

Address \_\_\_\_\_

City \_\_\_\_\_ Prov/State \_\_\_\_\_ Postal/Zip Code \_\_\_\_\_

Daytime Phone No. \_\_\_\_\_ Email \_\_\_\_\_

Product defect: \_\_\_\_\_

Type of payment      Cheque/Money Order       Visa       MasterCard

Name on card \_\_\_\_\_ Expiry Date \_\_\_\_\_ CSV No \_\_\_\_\_

Card No. \_\_\_\_\_

To contact our Customer Service Department:

SALTON CANADA  
81A Brunswick,  
Dollard-des-Ormeaux, Quebec H9B 2J5  
Canada

Telephone: 514-685-3660 (Ext. 226)  
E-mail: [service@salton.com](mailto:service@salton.com)  
Fax: 514-685-8300  
[www.salton.com](http://www.salton.com)